



Passenger Lift Services

Operating A Powermatic Access Lift



Access Lift is stowed away.



Lift up box lock handle and press
"up" button on handset.

Lift will then power out.





Lift will continue to power out with finger remaining on "up" button, until it reaches end of travel.

If finger is kept on "up" button once lift has reached end of travel, lift will start to raise off storage lugs.





Once lift is between 75 to 100mm off storage lugs "up" button may be released.

Handrails can then be un-folded.





Once both handrails have been unfolded, extension platform may then be extended by means of grab handle located at the front of the tail lift.





Lift may then be raised and lowered using the two button handset to allow persons onto the tail lift platform, from floor and vehicle levels.





Once lift has been used, return the platform to 75-100mm above the stowage lugs.

The platform extension can then be pushed away into it's stowed position and the handrails can be folded away.





Once the lift platform has been returned to its stowage state, the “down” button can then be pressed, this will lower the lift platform onto the stowage lugs, and whilst the “down” button is remained pressed in the lift will power away into the stowage box.

Hold “down” button until lift is all the way inside the stowage box.





Access Lift is stowed away.