



Passenger Lift Services

Operating An Easy Access Lift

Version 1.0 04/09/06

By Tom Lewis

Before vehicle doors are opened ensure that the lift is not resting against them, by pressing the "UP" button continually until the lift is stowed away correctly.



To Deploy the lift, hold the "DOWN" button until lift has reached the ground. **DO NOT STAND IN FRONT OF LIFT DURING DEPLOYEMENT!!!**



Once the platform has reached the ground, the Roll off Ramp stops will then drop to enable the passenger(s) onto the tail lift.



To move the passengers between the ground and vehicle floor, use the 2 button pendent handset.



To stow the lift away, hold the "UP" button until the lift has attained its maximum vertical position. Then return pendant handset to its holder and close vehicle doors.

